

NINJA[®]

COJ105

OWNER'S GUIDE

COLD PRESS JUICER PRO





THANK YOU

for purchasing the Ninja® Cold Press Juicer



REGISTER YOUR PURCHASE

 registeryourninja.com

 Scan QR code using mobile device

RECORD THIS INFORMATION

Model Number: _____

Serial Number: _____

Date of Purchase: _____
(Keep receipt)

Store of Purchase: _____

TECHNICAL SPECIFICATIONS

Voltage: 120V-, 60Hz

Power: 150 Watts

**PLEASE READ CAREFULLY AND
KEEP FOR FUTURE REFERENCE.**

CONTENTS

Important Safety Instructions.....	4
Parts.....	6
Before First Use.....	7
Features.....	7
Using the Control Panel.....	7
Using the Filters for Pulp Control.....	7
Using the Juicer.....	8
Care & Maintenance.....	10
Cleaning.....	10
Storing.....	10
Overloading the Unit.....	10
Ordering Replacement Parts.....	10
Troubleshooting Guide.....	11
Warranty.....	12

TIP: You can find the model and serial numbers on the QR code label on the back of the unit by the power cord.

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ CAREFULLY BEFORE USE • FOR HOUSEHOLD USE ONLY

⚠ WARNING

To reduce the risk of injury, fire, electrical shock or property damage, basic safety precautions must always be followed, including the following numbered warnings and subsequent instructions. Do not use appliance for other than intended use.

- 1 Read all instructions prior to using the appliance and its accessories.
- 2 Carefully observe and follow all warnings and instructions. This unit contains electrical connections and moving parts that potentially present risk to the user.
- 3 **DO NOT** submerge the motor base or control panel in water or other liquids. **DO NOT** spray motor base or control panel with any liquid.
- 4 Take inventory of all contents to ensure you have all parts needed to properly and safely operate your appliance.
- 5 Always make sure pulp spout is securely in place before motor is turned on. **DO NOT** unfasten parts while juicer is in operation.
- 6 Be sure to turn the appliance off after each use. Make sure the motor stops completely before disassembling.
- 7 Turn the appliance **OFF**, then unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning. To unplug, grasp the plug by the body and pull from the outlet. **NEVER** unplug by grasping and pulling the flexible cord.
- 8 Before use, wash all parts that may contact food. Follow washing instructions covered in this instruction manual.
- 9 Before each use, inspect auger for damage. If a auger is bent or damage is suspected, contact SharkNinja to arrange for replacement.
- 10 **DO NOT** use this appliance outdoors. It is designed for indoor household use only.
- 11 This appliance has a polarized plug (one prong is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. **DO NOT** modify the plug in any way.
- 12 **DO NOT** operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner. This appliance has no user-serviceable parts. If damaged, contact SharkNinja for servicing.
- 13 This appliance has important markings on the plug blade. The entire supply cord is not suitable for replacement. If damaged, please contact SharkNinja for service.
- 14 Extension cords should **NOT** be used with this appliance.
- 15 To protect against the risk of electric shock, **DO NOT** submerge the appliance or allow the power cord to contact any form of liquid.
- 16 **DO NOT** allow the cord to hang over the edges of tables or counters. The cord may become snagged and pull the appliance off the work surface.
- 17 **DO NOT** allow the unit or the cord to contact hot surfaces, including stoves and other heating appliances.
- 18 **ALWAYS** use the appliance on a dry and level surface.
- 19 **DO NOT** allow children to operate this appliance or use as a toy. Close supervision is necessary when any appliance is used near children.



- 20 This appliance is **NOT** intended to be used by people with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 21 **ONLY** use attachments and accessories that are provided with the product or are recommended by SharkNinja. The use of attachments, including canning jars, not recommended or sold by SharkNinja may cause fire, electric shock, or injury.
- 22 **DO NOT** put your fingers or other objects into the juicer opening while it is in operation. If food becomes lodged in opening, use the tamper or another piece of fruit or vegetable to push it down. When this method is not possible, turn the motor off and disassemble juicer to remove the remaining food.
- 23 Keep hands, hair, and clothing out of the container when loading and operating.
- 24 During operation and handling of the appliance, avoid contact with moving parts.
- 25 **DO NOT** use the appliance if the rotating sieve is damaged.
- 26 **DO NOT** operate the appliance without the pulp container in place.
- 27 **DO NOT** microwave container or accessories provided with the appliance.
- 28 **NEVER** leave the appliance unattended while in use.
- 29 **DO NOT** juice hot liquids. Doing so may result in pressure buildup and steam exposure that can pose a risk of the user being burned.
- 30 **NEVER** operate the appliance without lids and caps in place. **DO NOT** attempt to defeat the interlock mechanism. Ensure attachments are properly installed before operation.
- 31 Before operation, ensure all utensils are removed from container. Failure to remove utensils can cause container to shatter and potentially result in personal injury and property damage.
- 32 **DO NOT** attempt to remove the feed chute chamber from the motor base while the auger is still spinning. Allow the appliance to come to a complete stop before removing attachments.
- 33 If the appliance is overloaded, the unit will temporarily disable the motor. Wait approximately 2 minutes before using again.
- 34 **DO NOT** juice hot ingredients.
- 35 Remove the seeds and pits from such as mangoes or plums, as well as peels and tough skins from fruits such as oranges, lemons, and limes, as they could damage the unit.
- 36 **DO NOT** add water to the feed chute while the unit is operating to clean the unit.
- 37 **DO NOT** submerge the motor base or control panel in water or other liquids.
- 38 **DO NOT** spray motor base or control panel with any liquid.
- 39 **DO NOT** attempt to sharpen auger.
- 40 Turn off the appliance and unplug the motor base before cleaning.
- 41 **DO NOT** add frozen fruit, frozen vegetables, or ice to the juicer.
- 42 Consumers with sensitivity to pulp may wish to strain their juice as a precaution.

SAVE THESE INSTRUCTIONS

PARTS

To purchase more accessories and find great recipes, visit ninjakitchen.com.

- A** Cleaning Brush
- B** Tamper
- C** Food Tray
- D** Feed Chute Chamber with Anti-Drip Lever
- E** Auger
- F** Black Filter (no pulp)
- G** Gray Filter (some pulp)
- H** Orange Filter (lots of pulp)
- I** Inner Pulp Spout
- J** Outer Pulp Spout
- K** Juice Jug
- L** Pulp Container
- M** Motor Base (power cord not shown)



BEFORE FIRST USE


IMPORTANT: Review all warnings on pages 4-5 before proceeding.

NOTE: All attachments are BPA free and dishwasher safe.

- 1** Remove all packaging materials from the unit.
- 2** Wash parts in warm, soapy, water, then thoroughly rinse and air-dry all parts.
- 3** Wipe control panel with a soft cloth. Allow it to dry completely before using.

FEATURES

USING THE CONTROL PANEL



START/STOP


Press once to start continuous running up to 12 minutes; press again to stop.

REVERSE

If the feed chute chamber becomes blocked or ingredients are not processing, press and hold REVERSE. There will be a beep and a brief pause, then the auger will rotate in the opposite direction. Release REVERSE to stop. Repeat as needed. Press START/STOP to resume normal operation.


USING THE FILTERS FOR PULP CONTROL

Control the amount of pulp by choosing the desired filter.




NO PULP

Use the black filter with the finest mesh for juice with no pulp.



SOME PULP

Use the gray filter with the larger mesh for juice with some pulp.



LOTS OF PULP


Use the orange filter with the largest mesh for juice with lots of pulp.

NOTE: For best results, we recommend using the **Gray (Some Pulp)** or **Orange (Lots of Pulp)** filter when processing soft fibrous fruits like berries, seeded melons, and pineapple.


USING THE JUICER

IMPORTANT: Review all warnings on pages 4-5 before proceeding.


- 1 Plug in motor base and place on a clean, dry, level surface such as a countertop or table.




- 2 Insert the auger into the feed chute chamber, then attach the desired filter onto the auger, with the metal portion of the filter on the bottom of the auger.




- 3 Attach the inner pulp spout to the feed chute chamber by installing at an angle, on top of the filter, then turning counterclockwise to lock in place. Ensure the word Ninja is facing up. Then attach the outer pulp spout by installing at an angle, on top of the inner pulp spout, and turning counterclockwise to lock in place.



- 4 Install the assembled feed chute chamber on the motor base at an angle, then turn counterclockwise until it clicks into place.




- 5 Install the food tray on the top of the feed chute.



- 6 Place the pulp container under the pulp spout, then place the juice jug under the anti-drip lever on the feed chute chamber.


IMPORTANT: DO NOT add frozen fruits and vegetables or ice to the unit.

NOTE: If the feed chute chamber becomes blocked or ingredients are not processing, press and hold REVERSE. There will be a beep and a brief pause, then the auger will rotate in the opposite direction. Release REVERSE to stop. Repeat as needed. Press START/STOP to resume normal operation.




- 7 Select START/STOP, then gradually add ingredients to the feed chute. For best results, allow juicer to process each ingredient before adding more to the feed chute. Use the tamper to push ingredients down through the feed chute, as needed.

- 8 When juicing is complete, select START/STOP, then close the anti-drip lever. Stir juice and serve.



- 9 To disassemble, press and hold the RELEASE button while turning the feed chute chamber clockwise and remove from motor base.



- 10 Remove the pulp spout from the feed chute chamber by turning clockwise to remove the outer pulp spout, then twist the inner pulp spout clockwise to remove. Remove the filter and auger by gently pulling out of the feed chute.
- 11 Unplug the unit when finished. If moving the unit, grab from the bottom of the base. Refer to the Care & Maintenance section for cleaning and storage instructions.



To watch videos on how to use and clean the Ninja Cold Press Juicer, scan the QR code.

CARE & MAINTENANCE

CLEANING

IMPORTANT: DO NOT add water to the feed chute while the unit is operating to clean the unit.

• Hand-Washing

Separate all parts and wash in warm, soapy water with a soft cloth. Thoroughly rinse and air-dry all parts.

• Dishwasher

All parts, except the motor base, are dishwasher safe.

• Motor Base

Unplug the motor base before cleaning. Wipe with a clean, damp cloth.

DO NOT use abrasive cloths, pads, or brushes to clean the base.

• Using the Cleaning Brush

Use the included cleaning brush to clean hard-to-reach places, as well as remove excess residue.



Use the end of the cleaning brush to clear any buildup left over after juicing.



Use the bristle side of the cleaning brush to clean the filter, if needed.

STORING

For cord storage, wrap cord with hook-and-loop fastener near the back of the motor base.

DO NOT wrap the cord around the bottom of the base for storage.

When moving the unit, lift from the bottom of the motor base. Store the auger and filter assembled in the feed chute chamber with the pulp spout installed. Place the juice jug into the pulp container for easy storage.

OVERLOADING THE UNIT

This unit features a unique safety system that prevents damage to the motor and drive system should you inadvertently overload the motor. If the unit is overloaded, the motor will be temporarily disabled. Should this occur, wait 2 minutes, then press START/STOP to start the unit.

If your unit needs servicing, please call Customer Service at 1-877-646-5288. So we may better assist you, please register your product online at registeryourninja.com and have the product on hand when you call.

ORDERING REPLACEMENT PARTS

To order additional parts and attachments, visit ninjaccessories.com.

TROUBLESHOOTING GUIDE

⚠ WARNING: To reduce the risk of shock and unintended operation, unplug unit before troubleshooting.

The REVERSE program is not operating.

- After pressing and holding REVERSE, there will be a beep and a brief pause, then the auger will rotate in the opposite direction. Release REVERSE to stop. Repeat as needed. Press START/STOP to resume normal operation.

There is a buildup of pulp in the feed chute chamber.

- There may be a clog in the pulp spout. Press START/STOP to stop the unit, then remove the pulp spout. Use the end of the cleaning brush to clear the clog, then reinstall the pulp spout to the feed chute chamber. Resume juicing.
- For best results, allow juicer to process each ingredient before adding more to the feed chute. Use the tamper to push ingredients down through the feed chute, as needed.

The unit stopped working and is beeping.

- The unit was overloaded with ingredients. Wait 2 minutes then press START/STOP to start the unit.

Can I juice fruit with seeds and pits in it?

- No. Seeds and pits should be removed from the fruit prior to juicing. For example, remove the seeds from cherries and the pit from a plum.

Can I juice frozen fruits and vegetables or add ice?

- No, do not use frozen fruit, frozen vegetables, or ice with this unit.

The unit makes a squeaking noise when I juice certain ingredients.

- When the auger is breaking down fibrous ingredients like apples, celery, herbs and leafy greens, the unit will sometimes make this noise. This is normal and not a cause for concern.

There is clogging in the pulp filter.

- When juicing solely fibrous ingredients, such as pineapple, you may have to clear the filter of pulp more often, especially when using the no pulp filter.

The unit is producing less juice than I anticipated based on the amount of produce I used.

- With the Ninja Cold Press Juicer, you can expect 1 lb. of produce to yield approximately 8 oz. of juice.*
- Depending on the seasonality of ingredients, you may experience lower juice and pulp yield when using the No Pulp Filter. If this occurs, try using the Some Pulp Filter.

*Yield may vary depending on produce.

SharkNinja Operating LLC
US: Needham, MA 02494
CAN: Ville St-Laurent, QC H4S 1A7
1-877-646-5288
ninjakitchen.com

Illustrations may differ from actual product. We are constantly striving to improve our products, therefore the specifications contained herein are subject to change without notice.

NINJA is a registered trademarks of Shark Ninja Operating LLC.

For SharkNinja U.S. patent information, visit sharkninja.com/uspatents/

© 2021 SharkNinja Operating LLC

PRINTED IN CHINA

COJ105_IB_MP_Mv3



@ninjakitchen