



NO DIG. NO SQUISH.

ULTIMATE DRY ZONE.

Ninja FrostVault™ Technology delivers food-safe fridge temps for hours under 40°F. Keeps your food cold, dry, and separate from the main compartment full of ice.

GET THE MOST OUT OF YOUR COOLER

PRE-CHILL



Leave your Ninja FrostVault™ open in a cool space for a few hours before using. For better results, fill with ice. Empty when ready to use, then fill with fresh ice, pre-chilled items, and frozen dry zone ice packs.

PACK EFFICIENTLY & KEEP CLOSED



Fill the cooler completely with ice, food, and drinks. We recommend filling the main compartment with a 2:1 ice to food/drinks ratio. Keep cooler lid closed and keep in a shaded area to retain cold temperatures. Equally distribute food and drinks in the main cooler and dry zone for easiest transportation.

DRY ZONE FILL



Install the ice packs in the dry zone elastic straps then fill completely with pre-chilled food or drinks. **DO NOT** add ice to the dry zone. Keep dry zone closed and zipped when not in use to retain cold temperatures.

KEEP YOUR COOLER CLEAN



Before first use and after each use, clean with warm, soapy water. Rinse thoroughly and dry with a soft towel. Scrub gently on tough spots or stains as needed. Leave open and let air dry fully before storing.