


Please make sure to read the enclosed safety instructions prior to using your unit.

NINJA CREAMi Breeze™

Quick start guide



NOTE: Unit color, pint quantity, and programs may vary by model.



SCAN & WATCH
HOW IT WORKS
ninjacreami.com



SCAN & WATCH
HOW IT WORKS
ninjacreami.com

Perfectly personalized ice cream

PREP: 5 minutes | FREEZE: 24 hours | PROGRAM TIME: 1 1/2 minutes | MAKES: 4 servings

INGREDIENTS

1 tablespoon (1/2 ounce) cream cheese
1/3 cup granulated sugar
3/4 cup heavy cream

Flavoring, 1 teaspoon extract of your choice
OR 2 tablespoons of cocoa powder
1 cup whole milk
1/4 cup of your favorite mix-ins (optional)

PICK YOUR FLAVOR



Cocoa powder



Vanilla extract



Mint extract



Almond extract



Fruit extract

MAKE IT DAIRY-FREE Use vegan cream cheese for cream cheese, **unsweetened** coconut cream for heavy cream, and **unsweetened** oat milk for milk. Whisk the coconut cream until smooth, then add the remaining ingredients.



Microwave the cream cheese for 10 seconds. Add sugar and flavor, then whisk the mixture until it looks like frosting.



Slowly mix in heavy cream and milk until sugar is dissolved.



Pour base into CREAMi Breeze™ Pint. Place storage lid on pint and **freeze for 24 hours.**



Remove storage lid from frozen pint. Refer to next page for Assembly & process instructions.

Select **ICE CREAM.**

PICK YOUR MIX-INS TO ADD A PERSONAL TOUCH

1/4 cup of your favorite crushed candies, frozen fruits, chopped nuts, chocolate pieces, and more.



With a spoon, create a 1 1/2-inch wide hole that reaches the bottom of the pint. Add mix-ins to the hole in the pint and process again using the **MIX-IN** program.



Assembly & process



1. Plug in unit first

The unit will not run if the CREAMi Breeze Pint is installed before the unit is plugged in.



2. Prepare CREAMi Breeze™ Pint

Remove storage lid from frozen CREAMi Breeze Pint and check that the ingredients have not been frozen at an angle.



3. Install Creamerizer™ Paddle

Press and hold the paddle latch on the top of the processing lid, then insert the paddle in the bottom of the processing lid. Release the latch to secure the paddle.



4. Install Processing Lid

Position the processing lid on top of the CREAMi Breeze Pint. Twist the lid clockwise to secure pint. This can be verified by ensuring that the arrow on the processing lid is aligned with one of the arrows on the pint.

NOTE

If the install light is blinking and the power light is solid, make sure the pint is properly installed, and the lid is fully secured. This can be verified by ensuring that the arrow on the processing lid is aligned with one of the arrows on the pint. If both the power light and install light are flashing, make sure the paddle is installed in the processing lid.



5. Install CREAMi Breeze Pint

Insert the CREAMi Breeze Pint into the motor base. Rotate clockwise to lock, until you hear a click.



6. Select program

Press the power button, then press the program that suits your recipe.



7. Remove CREAMi Breeze Pint

When the program ends, press the release button on the front of the motor base to remove the CREAMi Breeze Pint.



MIX-IN



RE-SPIN



8. Remove Processing Lid

Rotate processing lid counterclockwise to separate from CREAMi Breeze Pint.



If adding mix-ins, use a spoon to create a 1 1/2-inch wide hole that reaches the bottom of the pint. Add chopped or broken mix-ins to the hole in the pint and process again using the **MIX-IN** program.

OR



9.

If not adding mix-ins, **RE-SPIN** can be used on a crumbly or powdery pint to make it creamy. **RE-SPIN** is often needed for very cold bases. Do not **RE-SPIN** before using **MIX-IN** program.

Disassembly & cleaning



Remove pint, processing lid & paddle

When the program ends, press the release button on the front of the motor base to remove the CREAMi Breeze™ Pint. Untwist processing lid from the CREAMi Breeze Pint and rinse the processing lid to remove any sticky residue or pieces wedged in the paddle. Then remove the paddle by sliding the paddle latch on the top of the processing lid.

All parts are dishwasher safe (top rack only and should NOT be cleaned with a heated dry cycle) and can also be hand-washed. Ensure the paddle, pint, processing lid, and storage lid are all separated before placing them in the dishwasher. The processing lid should be placed down horizontally.



Processing Lid
Locks Creamerizer Paddle in place.



Creamerizer™ Paddle
This dual-functioning paddle finely shaves and mixes frozen ingredients into the creamiest treats.



CREAMi Breeze™ Pints & Lids
BPA-free pints and lids for making and storing CREAMi treats.

NOTE: Unit color and programs may vary by model.

GET HELP RIGHT NOW!
DON'T RETURN TO THE STORE.
Questions or Problems?

CALL US: 1-877-646-5288
Toll-free customer support line

OR

Scan the code for
online help, FAQs,
and How-To Videos.
Ninjacreami.com

