

QUICK START GUIDE

BEFORE YOUR FIRST BREW

IMPORTANT: Ensure you prime your coffee maker before your first brew.

TO PRIME YOUR COFFEE MAKER:


- 1 Clean all accessories before your first brew.
- 2 Plug in the power cord and the coffee maker will turn on automatically.
- 3 Lift the water reservoir off its base. Remove the reservoir lid. Fill the reservoir up to at least the 710 mL (24 oz.) line with fresh water and place it back on the base.
- 4 Open the coffee maker lid, remove the Ninja Pod Adapter and insert the Permanent Filter. Do not add coffee; close the lid.
- 5 Place a 710 mL (24 oz.) cup under the nozzle and prime the system by running a 710 mL (24 oz.) Classic brew with water only.
- **6** Once the brew is complete, discard the water; coffee maker is now primed for use.

NOTE: If using the brewer in a highaltitude area, running a calibration brew is required. Not running a high-altitude calibration brew in a high-altitude area will result in excessive steaming during brewing. Refer to page 5 of the Owner's Guide for instructions on running a highaltitude calibration brew.

WHAT'S IN THE BOX



NINJA PODS & GROUNDS COFFEE MAKER



1.65 L (56 OZ.) REMOVABLE WATER RESERVOIR



ADJUSTABLE CUP TRAY



BREW BASKET

Comes fully installed in the brewer. It must always be inserted when brewing pods or grounds.



NINJA POD ADAPTER

Comes fully installed in the coffee maker. Ninja Pod Adapter must always be inserted in the brew basket when brewing pods.



PERMANENT FILTER

Located in the adapter storage on the right side of the unit. Permanent Filter must always be inserted in the brew basket when brewing grounds.



ADAPTER STORAGE BIN



NINJA SMART SCOOP™

Use this to measure coffee grounds.

USING THE NINJA POD ADAPTER AND PERMANENT FILTER

The Ninja Single-Serve Pods & Grounds Coffee Maker comes with the unique Ninja Pod Adapter already installed and a Permanent Filter in the Adapter Storage Bin located on the right side of the coffee maker. Always ensure the Ninja Pod Adapter or Permanent Filter is installed in the brew basket.



INSTALLING THE NINJA POD ADAPTER

Place the Ninja Pod Adapter in the brew basket, ensure the handle is aligned with the brew basket handle, and press down on the Ninja Pod Adapter firmly until it clicks into place.




INSTALLING THE PERMANENT FILTER

Place the Permanent Filter in the brew basket and ensure the handle is aligned with the brew basket handle.



ADAPTER STORAGE BIN

The adapter storage is located on the right side of the unit and can be used for both the Permanent Filter and Ninja Pod Adapter.




2 For how-to videos and more, visit ninjakitchen.ca Questions? 1855 520-7816 3

CHOOSE A METHOD



GROUNDS

- Place the Permanent Filter in the brew basket.
- 2 Using the Ninja Smart Scoop, measure out grounds following the measurements on the scoop or in the chart below.



COFFEE MEASUREMENT CHART

Serving Size	Ninja Smart Scoop
192 mL (6 oz.)	2-3 Scoops
251 mL (8 oz.)	
281 mL (10 oz.)	
340 mL (12 oz.)	
414 mL (14 oz.)	3-5 Scoops
541 mL (18 oz.)	
710 mL (24 oz.)	5-7 Scoops


3 Close the Permanent Filter and then the coffee maker lid.



PODS

- 1 Place the Ninja Pod Adapter in the brew basket.
- 2 Place a pod in the Ninja Pod Adapter.

IMPORTANT: Ensure the pod is not damaged. torn, or expired. **DO NOT** remove the top of the K-Cup Pod.



3 Press the coffee maker lid down firmly to pierce the pod and ensure that the lid is completely closed. There will be an audible click and some resistance when closing the handle as the needle punctures the pod.



SELECT A BREW STYLE



Smooth, well-balanced flavor.



More intense flavor that stands up to milk, cream, or flavoring.



Specially designed to brew hot over ice for freshly brewed iced coffee that is not watered down.

Always fill your vessel to the top with ice cubes before brewing Over Ice.

SELECT A SIZE



192 mL 340 mL 251 mL 281 mL (6 oz.) (8 oz.) (10 oz.) (12 oz.)



251 mL 192 mL 281 mL 340 mL 414 mL 541 mL 710 mL (8 oz.) (10 oz.) (6 oz.) (12 oz.) (14 oz.) (18 oz.) (24 oz.)

*Approximate brew volumes based on Classic brew. Rich brew will produce slightly less output. Refer to the Approximate Brew Volumes chart in the Owner's Guide for more information.

BREW



Press the BREW BUTTON to start brewing. A confirmation beep will sound and the progress bar on the control panel will illuminate to indicate the status of the brew.

NOTE: THE BREW MAY PAUSE ONCE OR MULTIPLE TIMES DURING THE BREW CYCLE. THIS IS NORMAL. Pausing allows the coffee grounds to fully extract and unlock the full flavor of the brew style.

NOTES		NOTES
	_	
	-	
	-	
	-	
	_	
	-	
	-	
	-	
	-	
	-	
	-	
	-	
	_	
	-	
	-	



For questions or to register your product, contact us at 1855 520-7816 or visit us online at ninjakitchen.ca





@ninjakitchencanada

PB040C_QSG_E_MP_MV4
© 2023 SharkNinja Operating LLC
NINJA is a registered trademark of SharkNinja Operating LLC.
NINJA SMART SCOOP is a trademark of SharkNinja Operating LLC.